



1. APPLY TEFLON TAPE OR EQUIVALENT SEALANT TO ALL PIPE THREADS BEFORE INSTALLATION.
2. INSTALLATION OPTION #1, STANDPIPE MOUNTING TO BACK OF SENSOR. (SHOWN)
3. INSTALLATION OPTION #2, 2.0" STANDPIPE MOUNTING TO JET CLEANER HOUSING.

CLEANER MODEL	PARTS OF ASSEMBLY	PART NUMBER	QTY.
C37	HOUSING CPVC 2" NPT	B5110-0001	1
	JET TUBE SS 316	B5205-0040	1
	ADAPTER POLYPRD 1/4"	B4953-0003	1
	SCREW SS 316 10-32x3/8"	B4704-0001	1
B37	HOUSING KYNAR 2" NPT	B5110-0002	1
	JET TUBE Ti Gr2	B5205-0041	1
	ADAPTER KYNAR 1/4"	B4953-0004	1
	SCREW Ti 10-32x3/8"	B4704-0002	1

C37 MAX 100C
B37 MAX 130C

REVISIONS					DIMENSIONS IN INCHES		SUBMERSIBLE JET CLEANER C37 / B37	
REV	DATE	DESCRIPTION	DWN	APVD	TOLERANCES UNLESS OTHERWISE SPECIFIED			
-	05/13/10	SEPARATE DWG'S	WC	HWM	DECIMALS	FRACTIONS	DWG # 2P0183 CHKD APPVD	
					.0000 +/- .0005	+/- .015		
					.000 +/- .005	ANGLES		
					.00 +/- .010	+/- 30MIN		
					.0 +/- .15			
					DRAWN BY W. COWAN		5200 Convair Drive Carson City, NV 89706 PH(775)883-2500 FAX(775)297-4740	
		SCALE	DATE	SIZE				
		NONE	XXXX/2010	B				